



# TOP OVEN SWITCH DIAGRAM

ET. 537438

B&S model 3043/16 : 16A 250V~ 10A 400V~ T150°C




EGO model 49.24815.806 : 16A 250V~ 10A 400V~ T150°C



# BOTTOM OVEN SWITCH DIAGRAM

ET. 537437

B&S model 3095/4 : 16A 250V~ 10A 400V~ T150°C



## Function

